

Mobile Power Supply

User Manual

14 April 2021

The MBLSRVPR power supply is designed to provide regulated power to a mother board and external devices. The input is the “12 volt” battery from a vehicle. There are two 50W Boost-Buck power supplies on the circuit board. A serial port allows for configuration of the supply.


An on-board microprocessor (uP) and sensors for voltage, current and ambient temperature can boot and shut down the server by mimicking the chassis front panel “power” button. Several measurements have their maximum values saved in non-volatile memory that can be examined using the serial port.

The uP ensures that the motherboard will not be booted if the ambient temperature is outside of the user set limits. It will also take down the server if during operation the temperature gets outside of the limits after a user programable period. Similarly, if the battery voltage goes below a user defined limit, the server will be taken down and the supplies shut off after a user programable period.

In addition to the battery input to the power supply, the “ignition” wire from the vehicle is connected to the supply. This is used to boot the server when the vehicle is started after a programable delay. When ignition goes away (there is no voltage applied) the server will be taken down after a programable delay.

The net result is from the users’ point of view, the server is available if the vehicle is running with no action needed by the user. The vehicle battery can’t be drain down so low that the engine can’t be started. The motherboard won’t be booted if it’s outside of its operating temperature range. This allows the motherboard to be an inexpensive grade consumer or small server product.

32 Overview of the Supply PCB:



33

34 The power supply form factor is such that it can be placed next to a Mini-
35 ATX mother board in a chassis that is designed for a Flex-ATX mother
36 board. Airflow should be from left to right w/r/t/ the above picture, which
37 works since most of these chassis, like the SuperMicro SCE300, have the
38 fans in the front of the chassis. The battery and ignition come into the
39 supply from the “rear” of the chassis. A connector such as an Anderson Power
40 Pole style is suggested. 16 gauge wire connected to the power supply can
41 be routed through the vent holes in the chassis and then the connector
42 attached to the wires. A color coding of black for ground, red for battery
43 plus and orange for ignition is suggested. This results in a 3 pin connector,
44 making it easy to remove the entire server from the vehicle for servicing.

45 All user connections on the power supply have voltage spike protection,
46 and many also have fuses. Use static protection when handling the board.

47 When removing the 15 amp fuses, press down on the large white
48 choke/coil and Serial Port connector. Then lift up on the fuses to avoid
49 flexing the printed circuit board (PCB). Rubber feet on the bottom of the
50 boards allow fuses and the 10 pin connector to be inserted by pressing
51 down on the board without the risk of flexing too much.

52 When removing the serial port connector, press on the fuses and orange
53 Ignition connector to avoid flexing the PCB too much.

64 connect ignition to the top terminal labeled as “IG” the PCB which may also
65 be colored as shown.

66 J6 is a DB-9 female serial port used to configure the supply. Use a
67 standard DB-9 Male to USB adaptor cable to connect to your PC. The baud
68 rate is 57600. “8-none-1”, no flow control.

69 J7 is a 10-pin ribbon connector that connects to your mother board so that
70 the power supply can tell the OS what is going on. This is a one-to-one
71 match for the SuperMicro A2SDI-xC-HLN4F series motherboards. The “xx”
72 is the core count, and can be -2C, -4C or -8C. The pinout for J7 is:

73	DB9		Header		DB9
74			-----		
75	6		2 1		1
76	7		4 3		2
77	8		6 5		3
78	9		8 7		4
79	Nc		10 9		5
80			-----		


81 Note that other SuperMicro server motherboards have a different
82 pinout for the 10-pin serial headers. Be sure to check your motherboard
83 manual.

84 J10 is for the “beeper”. Typically the two wires will go to a 4 pin header
85 connector that is on the mother board. There is no polarity on the beeper.

86

87

88 On the Left side of the supply PCB there are more user connections:



89

90 The power supply form factor is such that it occupies the empty space in a
 91 SuperMicro SCE300 chassis. That chassis it for a Flex-ATX mother board.
 92 When using the A2SDI-xC-HLN4F series Mini-ATX mother boards, there is
 93 a space left in the chassis. The power supply mounts in this space. That
 94 chassis has a 5.5mm/2.5mm “barrel connector” jack on the back with two of
 95 the 4-pin connectors on wires. One of those sets of connectors is cut from
 96 the barrel connector, the bare ends are insulated with heat sink at the
 97 barrel connector, and the wires on the cut-off connector goes to J3. The
 98 two yellow wires to the +12, the two back wires to the GND. The 4 pin
 99 connector then goes to the motherboard to provide power. This is the
 100 Server supply.

101 The remaining 4-pin connector, which is still wired to the rear
 102 5.5mm/2.5mm barrel connector plugs into J4, the white 4-pin connector, to
 103 provide power out of the server chassis to user devices that need power
 104 This is the 2nd 50 W supply called the Auxiliary (or AUX) supply. The screw
 105 terminal connector J5 can also be used to connect to the Auxiliary (AUX)
 106 power supply.

107 There are small green LEDs next to the server supply output and the aux.
 108 supply output that are illuminated when the supply has voltage. There is
 109 also a small green LED next to the J7 10 pin Server Serial Port connector
 110 that is dimly lit when the uP power supply is on, indicating that the on board
 111 microprocessor is up and running.

112 J8 connects to the chassis front panel. There is a 16 wire ribbon connector
113 that goes from the panel to the mother board. The “power” button is a
114 “shorts when you press it” button that has one side at Ground and the other
115 shows about 3.3V. This is connected to J8 by extending the 2 wires on the
116 ribbon cable. You have to make this “special” version of the front panel
117 ribbon connector. The “right” pin (PCB oriented as in the above picture) is
118 Ground, as indicated by a small ‘G’ on the PCB. The “left” pin is the active
119 signal to and from the switch. The supply uP can both pull this pin to
120 ground to boot or take down the server and can monitor the pin in case the
121 user presses the button to take the server down manually.

122 The connector is a Molex connector with these part numbers:

123 2 pin header: 22-01-2027

124 Pins: 08-50-0113 (cut strip with 100 pins on it)

125 While this connector is hard to solder the wires to, and difficult to insert the
126 pins into the header, when done right the connector can only be inserted
127 one way on the supply board. As such, it is hard to get the polarity
128 swapped by mistake. Note that the pin spacing is .1”, so other connectors
129 with screw terminals could be user installed.

130 J9 is an “Open Collector” connector. Under software control, the supply can
131 pull a signal to ground. The user can configure what state the supply must
132 be in to activate the pull to ground transistor. This output has a Transient
133 Protection Diode (abbreviated TVS, go figure). It also has 140 mA self-
134 resetting fuses on both the output and the ground connection. The ground
135 connection is at power supply and server mother board ground. The
136 maximum current that can be pulled to ground is 50 mA, enough for a small
137 relay if you need to work at higher currents.

138 **Header Shorting Pins:**

139 There are two areas where users can install “shorting headers” onto the .1”
140 pins:

141 J20 is on the left side of the boards. There are two headers with horizontal
142 orientation that can be installed. If the “top” header, which is red in the
143 above picture, is installed the supply will always be “on” when there is
144 battery applied. This makes the supply look like a more conventional supply
145 without the ignition turn-on feature. There is “AON” text above this header
146 on the PCB.

147 The “bottom” header, which is black in the above picture, is used to enable
148 changes in the configuration. It is above the “CONF” text on the PCB.

149 When installed, the user configuration serial port can be used to change

150 the supply voltages and current limits. The other parameters described in
151 the software section can be changed. When not installed, information can
152 be viewed but not changed.

153 J21 is on the right side of the board. If this jumper/shorting header is
154 installed, whenever there is battery power the uP is running. This is useful
155 for turning on the uP so you can configure the device with the serial port. It
156 also must be installed for the system to work when configured to look like
157 an “ordinary” power supply.

158 If you want the server to boot when battery voltage is applied, you should
159 short out both J20 “top”/“AON” and J21. Note that you must take the server
160 down manually with the front panel button, and wait for the server to go
161 down before disconnecting the battery voltage.

162 **Other Connections you probably shouldn’t use:**

163 For the sake of completeness, here are other connections that are not
164 intended to be used by the typical user:

165 J99 is a 3-pin Molex connector used to “flash” (download) the software into
166 the microprocessor.

167 J101 is a 5 pin header that has Ground and 4 signals. It is used for
168 debugging when doing software development and can be used to output
169 other signals depending on the power supplies state. Connect to these at
170 your own risk if you are using these advanced features.

171 J23 can be used to connect the power supply ground directly to the chassis
172 if you carefully scrape off the solder mask on the screw hole. This
173 connection is after the EMI filtering and fuses. In some situations, this may
174 improve EMI performance.

175 J24 is between the two big gray inductors. It provides access to the filtered
176 battery supply in case that is needed for some other device. This is after
177 the fuses, and as such there is not much power available without starting to
178 impact the current available for the two power supplies. A standard .2”
179 screw terminal connect can be applied here.

180 Finally, there are four small holes on a diagonal around the “CONF” text.
181 These connect to 3.0 volts, Ground, and the I2C signals of SDA and SCL.
182 The intent here is to have some way to add another sensor to the board for
183 some use that was not anticipated at the time of design. If you’re using this
184 feature, and using the J101 connections, you are also writing your own
185 software for this platform and you’re on your own with no warranty.

186 **The Fault and OK diagnostic LEDs:**

187 There is a red “Fault” and green “OK” led on the PCB as seen on the
188 picture above. They indicate the state of the system. Each led can display
189 any of the following patterns:

190 Always on or off.

191 Fast or slow “blinking” (50 percent duty cycle).

192 Fast or slow “Winking” (80% on, 20% off)

193 Fast or slow “Flashing” (20% on, 80% off)

194 The pattern seen indicates the state of the software. For example, when
195 the green OK led is blinking fast, the ignition is on and the system is waiting
196 to turn on the supplies. When the LED blinks slow, the supplies are on and
197 soon the mother board will be “booted”. When the green LED is on all the
198 time, the system is up.

199 The red fault LED can be on and yet everything is OK. It just means that at
200 some point in time, there was a brief fault that occurred. The user
201 configuration serial port can be used to see what the problem was.

202 Technicians who install and maintain servers using this power supply can
203 use these two LEDs to have some idea of what is going on. Note that the
204 serial port can also be configured output what state the system is in,
205 providing detailed feedback about the system. This is done via the
206 Hardware Configuration Bitmask, described later in this document.

207

Electrical Specifications:

Input voltage:

Range: 7.5 to 18V. The input can briefly (< 100 mS) dip down to 6.5 volts during vehicle cranking. The limitation here is exceeding the 15 amp input fuse rating for too long.

Maximum continuous battery current: 14 Amps

Note that at 12V output and 7.5 V input, an individual supply will draw 7.2 amps.

Standby Current: When the ignition is off, the board draws less than 10 micro amps of current.

Quiescent Current drawn by the microprocessor:

< 40 mA

Server Supply:

Output Range: 1.8 to 13 V

Server Supply Current Max: 8.1 to 13V: 4.8 Amps
1.8 to 8V: 5.8 Amps

Note: 4 A continuous load is recommended. (5 A for < 8.1 V)

Auxiliary (AUX) Supply:

Output Range: 1.8 to 18V

Aux Supply Current Max: 8.1 to 13V: 4.8 Amps
1.8 to 8V: 5.8 Amps

Note: 4 A continuous load is recommended. (5 A for < 8.1 V)

Both supplies can provide currents up to 15 amps for 3 mS before an over-current event is logged and the supplies “fold back” to a current limited mode of 5 ($V_{out} > 8$) or 6 ($V_{out} \leq 8$) amps. This allows for step changes in load, particularly for capacitive or high inrush currents, to be accommodated while maintaining sufficient voltage regulation.

The power supplies can be shorted with no damage to supplies.

If the output voltage is set to exceed 12 V, there will be some current derating when the supply is operating in Boost mode and the battery voltage is less than the set output voltage. User must test to determine if supply is suitable in these situations. Making 18V on only 7.5 volts in will draw a substantial amount of current, much more so that making 12V out.

241 As such, the available current when running in boost mode is derated as
242 the set output voltage goes above the typically battery input voltage.

243 *Temperature Range:*

244 The range over which the supplies will be turned on (produce output
245 voltage) and boot the server is user configurable, but can not exceed a
246 range of 32 to 138 degrees F. The power supply board can function from
247 minus 40 to + 185 degrees F, but if the ambient is outside of the user
248 configurable range the uP will just wait for the temperature to be in range
249 before turning on the power supplies. The on board uP and it's power
250 supply will work over that temperature range. Note that the environmental
251 and ambient temperature restrictions of the mother board should dictate the
252 operational range for the supplies, and some degree of margin should be
253 used when setting the operation range. The default range of the supply
254 (prior to user modification) is 35 to 130 degrees F. This is for the
255 SuperMicro A2SDI-xC-HLN4F series motherboards. If the ambient
256 temperature is out of range, the uP will wait until the temperature is in
257 range, and only then turn on the power supplies and boot the system.

258 Humidity must not be such that condensation on the PCB can occur. Like
259 most motherboards, the power supply is not conformal coated.

260 *Vibration:*

261 The components on the power supply are similar to the components used
262 on a motherboard. They are not AEC-Q200 automotive grade parts. It is
263 suggested that the chassis be mounted in the vehicle using some form of
264 shock absorbing material, such as shock mounts or a cushion. Note also
265 that the motherboard/OS should use SSDs for storage.

266 *Front Panel Power Switch:*

267 *Maximum sink current: 50 mA*

268 *Maximum input voltage: 3.6 V*

269 *Pull to Ground (PTG) Output:*

270 *Maximum sink current: 50 mA*

271 (fused at 140 mA on both the output and ground connections)

272 *Maximum input voltage: 18 V*

273 *Voltage and Current Measurement Accuracy:*

274 *Voltage Measurements: $\pm 1\%$*

275 *Power Supply Current Measurements: $\pm 2\%$*

276 *Battery Current Measurements: $\pm 3\%$ (current > 1 amp)*

277 Battery current can be calibrated at a specific current level
278 which improves accuracy to 1% when operating at currents
279 within $\pm 25\%$ of the calibrated level.


280 *Ignition Input Voltage Threshold:*

281 $V_{in} < 1 \text{ Volt} \rightarrow \text{Off}$, $V_{in} > 2 \text{ Volt} \rightarrow \text{On}$, $V_{\text{threshold-Typical}} = 1.6 \text{ V}$

282 Input Impedance: Approximately 5K Ohms

283 *Input Voltage vs. Input Current:*

284 *Note: Power supply output at 12V with 4 Amp load*



285
286 Note that for both supplies at 12V with 4A load, the lowest continuous
287 sustained input voltage should not be less than 7.5 volts. At that input
288 voltage and load, the battery input current will be about 14.5 amps.

289 The supplies will be turned off if the battery voltage in dips below 6.3 volts
290 for any period of time. As such, the 6.5 to 7.5 voltage range allows for a
291 brief dip in voltage during initial 100 mS period when the starter motor is
292 engaged and at stall. When at stall the maximum current draw causes the
293 battery to dip to its minimum voltage.

294

295

Functional Description

296 *Use case:* Battery and Ignition connections. If the vehicle is running, the
297 server should be operational and booted. In this discussion, times and
298 other constants are taken from the default values of the power supply
299 control system that runs on the on-board microprocessor.

300

301 *Note: values that are user programable are blue.*

302

303 The vehicle and the server are off. The driver cranks the vehicle. In
304 the process, the ignition wire goes hot for a brief time (100 mS or so), then
305 goes off (no voltage) while the engine cranks. This would be an “old
306 fashion” rotating system where you “pass through” ignition to get to “crank”.
307 Once the engine starts and is running, the ignition wire goes hot again.
308 Push-to-start more current vehicles tend to not bump the ignition before
309 cranking.

310 The uP waits for the ignition to be hot (have voltage > 2 volts) for 2
311 seconds (This is user programable delay). During this time, the OK LED
312 slow flashes green (20% on, 80% off). It also waits for the battery to go
313 above 12 volts (This is a user programable threshold). Once it is above 12
314 volts the OK LED displays a fast blink. With ignition good and the battery
315 OK, the uP asserts a line that keeps it’s power on even if ignition goes
316 away. The processor waits until the ambient temperature is in range.

317 It then waits for 3 seconds before trying to turn on the supplies (This
318 is a user programable delay). If at any time the ignition drops or the battery
319 voltage goes < 12 Volts, the entire process starts all over again. After 3
320 seconds, the power supply chips are turned on. The OK Led displays a
321 slow blink.

322 Throughout the early start process, if the ignition goes away, the
323 temperature goes out of range or the battery goes low, the process starts
324 all over.

325 If the ignition and battery are still good, it then checks to see if the
326 ambient temperature is > 35 and < 130 degrees F (These are user
327 programable limits). If not it waits for the temperature to be within limits. If
328 the temperature is OK, it turns on the power supply chips. It then waits for
329 300 mS for the power supply chips to reset and stabilize. It then turns on
330 the server supply to 12 volts (This is a user programable voltage). The
331 green OK LED is still winking. It then waits 500 mS and then checks to be

332 sure the ignition is still hot. If so, it turns on the Auxiliary supply. Both
333 supplies are now on.

334 The uP then waits for 5 seconds before it tries to boot the
335 motherboard (This is a user programable delay). The Green OK LED is
336 now on all the time. Then the “boot” button (the front panel power button) is
337 “pressed” via J8 for 1.1 seconds. Once the server is told to boot, the
338 systems wait for either 60 seconds or for the current consumed by the
339 mother board to exceed 800 mA (This is a user programable current
340 threshold). When the mother board is turned on, the current is around 400
341 mA and the fans are running, and when Unix boots, the current is about 1.6
342 A.

343 At this point, everything is up and running. This is the state that the
344 uP will spend most of its time in. All next steps revolve around when to take
345 the system down.

346 If the ignition goes off, the system waits for 10 minutes before starting
347 the operating system shutdown procedure (This is a programable delay). If
348 the ambient temperature goes out of range, the system waits for 2 minutes
349 and starts the shutdown procedure. If the battery falls below 12 volts, the
350 system waits for 10 minutes and then starts the shutdown procedure (This
351 is a user programable delay). The shutdown procedure is different
352 depending on what event triggered the need to shut down. If ignition went
353 away and then came back, the system goes back to its steady state.
354 Similarly, if the temperature or battery come back into range, the system
355 goes back to its steady state.

356 Once the “turn off” event (whatever it was) timeout has passed, the
357 process of shutting down the system starts. The front panel switch is
358 asserted for 2 seconds to start the shutdown process. The system is
359 considered shut down if 90 seconds passes, or if the supply current drops
360 below 800 mA. The power supplies stay up for 10 more seconds so that the
361 fans in the chassis can continue to cool the motherboard components.

362 The power supplies are then turned off. 2 seconds later, the power
363 supply chips are turned off. 300 mS after that, the uP turns off its own
364 power supply and subsequently turns off, waiting for the ignition to go hot
365 again and the whole process starts anew. This last state where the uP
366 turns its power off is the “Goodbye Cruel World” state. When fully off, the
367 power supply current is the leakage current of the capacitors, typically
368 around 5 microAmps.

369 The state machine that runs all this has over 25 states.

370

371 *Use Case:* Battery power is applied, ignition is ignored, the entire system
372 just needs to power up and boot the system.

373

374 This process is much simpler. The hardware is configured with a
375 shorting jump on J21 and on the “AON” pins of J20. The system waits until
376 the battery voltage and temperature are within range and boots the
377 system.

378 If the battery voltage drops too low (below 12 volts) or if the ambient
379 temperature goes out of range, the above time delays occur and the
380 system is taken down. It then starts the process all over. The uP is always
381 on when in this state.

382 Before the user that provided power to the battery can remove the
383 power, the user must to press the front panel power button manually for the
384 2 seconds. Timing is everything here, the motherboard will shut down
385 without any system OS controlled shutdown if the button is pressed for too
386 long (typically > 4 seconds). When the system is finally down as
387 determined by the user power can be removed.

388 This would be used in the case where the server was plugged into a
389 power source and not necessarily hardwired into the vehicle. A “Portable
390 sever you can plug into a vehicles’ power system” scenario.

391

392 **Configuration Settings:**

393 The uP has nonvolatile memory that does not require a battery. In
394 that memory, various configuration parameters are stored. Using the serial
395 interface, the current settings can be viewed. Here is what might be seen
396 when displaying the settings:

```
397 Config/EEPROM settings:  
398 Configured by pete  
399 Server Supply Voltage=12000 mV  
400 Aux Supply Voltage=5000 mV  
401 Ignition to Power On Delay=3 Sec  
402 Power On to Boot Delay=5 Sec  
403 Bad Battery to Power Off Delay=600 Sec  
404 Bad Temperature to Power Off Delay=120 Sec  
405 Minimum Operating Temp.=35 F  
406 Maximum Operating Temp.=130 F  
407 Battery Max Current Threshold=14900 mA
```

408 Server Supply Max Current Threshold=4700 mA
409 Aux Supply Max Current Threshold=4500 mA
410 Ambient Max Temp. Seen=78 F
411 Ambient Min Temp. Seen=76 F
412 Ignition Loss to Shutdown=10 Minutes
413 Current when OS Running=800 mA
414 Battery OK Threshold=12000 mV
415 Fan Turn On =105 F
416 Fan Turn Off=90 F
417 Boot Press=111 x 10mS F:
418 Shutdown Press=210 x 10mS F:
419 Hardware Config. Bitmask=0x800

420

421 Given the above description of how the system works, many of these
422 settings should be clear. A few need an explanation though. Some of the
423 configuration values are used to establish *thresholds* for over current
424 events that are logged. There is an option that can be set to run a fan if the
425 ambient temperature is too hot. Finally, there is a hardware configuration
426 bitmask to enable a number of other functions that we will look at in a later
427 section. One of those options displays the state the system is in along with
428 the time spent in a state before transitioning to the next state. For a normal
429 “boot”, that state transition display looks like this:

```
430 0.0 State 0 -> 1 Have Ignition, wait to check Vbat...
431 1.5 State 1 -> 2 Wait to re-check Ignition...
432 3.3 State 2 -> 3 Monitor temp. and battery
433 0.0 State 3 -> 4 Turn on supply chips...
434 1.3 State 4 -> 5 Server Supply ON
435 0.0 State 5 -> 6 Server Supply stabilize
436 0.5 State 6 -> 7 Aux Supply ON, monitor Vbat & temp...
437 5.0 State 7 -> 8 Pre-boot Check
438 0.0 State 8 -> 9 Assert Boot Button
439 0.0 State 9 -> 10 Button Depress Delay
440 1.1 State 10 -> 11 90 seconds or Sever Booted wait...
441 90.0 State 11 -> 12 Everything running OK
```

442 State 12 is the steady state where everything is up and running OK. Note
443 that some delays are configurable, some are not. If the system is not
444 booting or appears to be hung up, seeing the states can help determine
445 what the problem is. Future firmware may not show the English description,
446 or they may be shorter is program memory space gets tight. (“may” =
447 “almost always”).

448

449 The User Configuration Serial Port

450 When the user has the serial port connection made, and the power supply
451 is turned on either by applying power to the ignition or by jumper-ing J20
452 “AON” and J21, the serial console is up and ready to be used. If the
453 “CONF” shorting jumper is installed, changes can be made. The user sees
454 this:

```
455 PS CTRL V 1.0  
456 >
```

457 The user can type a command. All commands are a single letter, with any
458 letters after that ignored. So “h” and “help” are the same command. That
459 command shows:

```
460 > h  
461     Terminate all commands with an 'Enter'.  
462     Type 'c' to configure  
463     'A' for current analog measurements.  
464     'i' to see Server supply I2C registers,  
465     'j' for Aux supply registers  
466     'd' to display current EEPROM settings  
467     'L' to blink LEDs briefly  
468     'P' On/Off:  ps1=turn on Server, ps0=turn off Server, pal=power on Aux  
469     'x' to clear all system faults, max currents & max temperatures  
470     '~' to reset EEPROM to default values  
471     'b' to calibrate battery current  
472     'r' to reset and re-boot
```

473

474 The ‘c’onfigure command lets you see and change configuration values.
475 You will see a value displayed and can either hit Enter/Return to go to the
476 next, or type in a new value and hit Enter/Return. You can quit at any time
477 by typing a ‘q’. Changes made prior to that will still be made, this is just
478 handy if you only want to change one value and don’t want to go through
479 the list. Here is an example of what you would see if you just wanted to
480 change the auxiliary supply output voltage:

```
481 > c  
482     Config Mode. 'q' to quit, Enter for next,  
483     or Type in value and Enter to change.  
484     'A' to see current measurements.  
485     Configured by pete:  
486     Server Supply Voltage=12000 mV:  
487     Aux Supply Voltage=12000 mV: 5000  
488     Ignition to Power On Delay=3 Sec: q
```

489

490

```
491 --- Exit Config Mode. ---  
492 Configuration done & saved. Changed 2 bytes.
```

493

494 Now displaying the configuration settings shows:

```
495 > d
496     Config/EEPROM settings:
497     Configured by pete
498     Server Supply Voltage=12000 mV
499     Aux Supply Voltage=5000 mV
500     Ignition to Power On Delay=3 Sec
501     Power On to Boot Delay=5 Sec
502     Bad Battery to Power Off Delay=600 Sec
503     Bad Temperature to Power Off Delay=120 Sec
504     Minimum Operating Temp.=35 F
505     Maximum Operating Temp.=130 F
506     Battery Max Current Threshold=14900 mA
507     Server Supply Max Current Threshold=4700 mA
508     Aux Supply Max Current Threshold=4500 mA
509     Ambient Max Temp. Seen=78 F
510     Ambient Min Temp. Seen=76 F
511     Ignition Loss to Shutdown=10 Minutes
512     Current when OS Running=800 mA
513     Battery OK Threshold=12000 mV
514     Fan Turn On =105 F
515     Fan Turn Off=90 F
516     Boot Press=111 x 10mS F:
517     Shutdown Press=210 x 10mS F:
518     Hardware Config. Bitmask=0x800
519
```

520 You can see that the aux supply voltage is now 5 volts. The units are
521 always in milliVolts or milliAmps. All the values have units after them.

522 The Boot and Shutdown Press set how long the front panel button on your
523 server is pressed to boot and take-down the system. The units are in “Jiffy”,
524 which is a 10 mS clock. A time of 111 means 1.11 seconds.

525

526 Now let us look at the current analog measurements:

```
527 > a
528     Bat V=13897 mV, I=236 mA
529     Server V=12017 mV, I=254 mA
530     Aux V=5008 mV, I=0 mA
531     Max Batt. I=3412 mA, Max Server I=2956 mA, Max Aux I=115 mA
532     Current Temp=78, Max Ambient.=78 F, Min Ambient=72 F
533     No Faults.
534     Low Battery Shutdown Count=2
535     I2C bus: 49 TMP116, 74 TPS55288 Server, 75 TPS55288 Aux
536     Power Supply State=12 Everything running OK
```

537 Configured By: pete

538

539 We can see that the aux supply is at 5 volts, and has no load on it. The
540 server supply is at 12V and has a small 254 mA load. The battery is at 13.9
541 volts and has a 236 mA load.

542 Note the maximum values logged for the battery, server supply, and aux
543 supply along with the temperature logs. Any faults will be displayed with the
544 appropriate English text. The I2C bus has found the temperature sensor
545 (TMP116 is the part number for the sensor) and the two power supply chips
546 (The power supply chip is a Texas Instruments TPS55288). The
547 configured by is a 31-character field that can be set to anything you can
548 type. It can show who last configured the unit and possibly a date- it is
549 whatever you care to type.

550 The types of faults you can see are (extracted from the software):

551 "Over Temperature", "Under Temperature", "Battery Current Over Limit",
552 "Server Current Over Limit", "Aux Current Over Limit", "Server Chip Short",
553 "Server Chip Over Current", "Server Chip Over Voltage", "Aux Chip Short",
554 "Aux Chip Over Current", "Aux Chip Over Voltage", "Faulty Temperature Sensor",
555 "Low Battery Shutdown"

556

557 As you can see, a lot of conditions are monitored. Sometimes a fault can
558 be ignored. If you connect a device with a large inrush current (due to a
559 heavy capacitive load), you may get a Over Current fault. None the
560 less, these faults can be useful for figuring out what the supply has been
561 subjected to while it was in use. The 'x' command (described later) can be
562 used to clear all the faults.

563

564 For the geeks in the crowd (and to help software developers) you can
565 display the values of the registers in the TPS55288 power supply chip:

```
566 > i
567     Server Supply I2C Registers:
568 R0-1 Vref=759  0x2F7 (901 mV)
569 R2 I Limit=229  0xE5 (50.5 mV, with .010 Ohm=5050 mA)
570 R3 Vout Slew Rate=17 (OCP_DELAY=1 -> 3mS, SR=1 -> 2.5mV/uS)
571 R4 Vout Feedback=2 (Internal feedback, internal ratio=2 -> 0.0752)
572 R5 CDC= E0  1110 0000  No CDC compensation
573 R6 Mode=B0  1011 0000  -- Output is ON --
574 R7 Status=1  Buck
```

575

576 The 'l' (lower case 'l' as in 'l'eds) command briefly turns on both LEDs and
577 is for diagnostics to be sure the LEDs are working.

578

579 The 'p' command can turn the power supplies on and off once they have
580 been turned on. This allows you to turn off a supply to wire up a device
581 without having to power down the entire system.

582

583 We saw with the 'a' command:

```
584 > a
585   Bat V=13897 mV, I=236 mA
586   Server V=12017 mV, I=254 mA
587   Aux V=5008 mV, I=0 mA
588   Max Batt. I=3412 mA, Max Server I=2956 mA, Max Aux I=115 mA
589   Current Temp=78, Max Ambient.=78 F, Min Ambient=72 F
590   No Faults.
591   Low Battery Shutdown Count=2
592   I2C bus: 49 TMP116, 74 TPS55288 Server, 75 TPS55288 Aux
593   Power Supply State=12 Everything running OK
594   Configured By: pete
595
```

596 The items in red are values logged by the system in non-volatile memory.
597 The 'x' command lets you clear/reset those values. You type the 'x', then as
598 per the printed instructions, type a control-D (^D). Any other character
599 aborts the clear. This command also clears the faults listed above in red.

```
600 > x
601   type ^D to clear all faults:
602   --- All faults have been cleared.
603   PS CTRL V 1.0
604
```

605 The tilde '~' command is similar, but it resets all the configuration/EEPROM
606 values to their factory defaults.

607

608 Finally, there is the 'b' command to calibrate the current sensor for the
609 battery. For technical people, the current sense resistor is two 3 milliOhm
610 resistors in parallel (1.5 mOhm). With this low value, small changes in the
611 solder depth as the part was soldered on the board can introduce errors.
612 While the accuracy is good enough for knowing if you're within the limits of
613 the supply, if you are typically operating at a given current, you can
614 calibrate the battery current sense. Note you will need an accurate amp
615 meter to measure the current. When you do this, you will also be trimming
616 out the quiescent current of the microprocessor. As such, at low currents (<

617 .5 amps) the battery current reading is less accurate and includes both the
618 power supply and microprocessor quiescent current. Here is what that
619 process looks like:

```
620 > b
621     type + or - to adjust, q or ^D to quit
622     Battery I=234 mA
623     type + or - to adjust, q or ^D to quit
624     Battery I=230 mA
625 -   Battery I=232 mA           (user typed a '-' here)
626 -   Battery I=240 mA
627 =   Battery I=232 mA           (user typed a '=' for plus here)
628 =   Battery I=238 mA
629 =   Battery I=236 mA           (user typed a control-D here)
630
631 Calibration Done
632
```

634 Note that you can type an '=' sign in addition to a plus so you don't have to
635 use the shift key.

636

Hardware Configuration Bitmask

637

638 A 16 bit "Hardware Config. Bitmask" can be configured by the user. The
639 default value of this bitmask is all zeros. From the software, here are the
640 meanings of the bits:

```
641  //// Bit assignments for hardwareConfigBitmask:
642  // D0  Take open collector output low if need a fan running
643  // D1  Take open collector output low if uP power is ON (independent of Ignition)
644  // D2  Open collector output is a mirror of the front panel push button to
645         boot (as driven by the uP). D6 & D7 affect this too
646         This can also be configured via D5 to be a "PowerOK"/"~Reset"
647         (active low reset, open collector/drain)
648  // D3  Take open collector output low if battery voltage is
649         OK (above the batteryOkVoltage)
650  //     Note: All battery voltage measurements have 200 mV of hysteresis.
651  // -----
652  // D4  Make P2.0-3 reflect all of the above D0 to D3 bits. D0-3 can still be set for
653         the Open Collector output.
654         // Note: the P2 pins are active high to set-up for driving an open collector
655         transistor for "pull to ground" low.
656  // D5  Front panel push button output used as a "Power Good"/"nReset". Goes low
657         before power up on boot, and goes low before power down on system take-down.
658         Can be used as "enable" for other systems. Functions as an
659         active high enable driven by an open collector transistor or FET
660  // D6  Open Collector output is a "PowerOk" or "~Reset". Allows use of P2.0-3pins
661         via the D4 bit and lets the Open Collector output be used for reset so all
662         5 control signals are available
663  // D7  (not used)
664  // -----
665  // D8  Don't "push" the front panel button on boot
666         (for systems that boot on power up)
667  // D9  Don't "push" the front panel button on power down
668  // D10 Don't use the server running current to determine if OS is stopped,
669         just wait for the OS_TAKE_DOWN_TIME (typically 90 seconds)
670         seconds boot time and assume system is down.
671  // D11 Print state transitions on Configuration Serialpport (Uart 1)
```

672

673 These bits can be used to define the function of the Pull to Ground output
674 connector. They can also be used to drive the J101 pins. Some change the
675 usage of the Front Panel Power Switch J8 to account for the default action
676 of some motherboards w/r/t/ when and how they boot. Some motherboards
677 boot on power up, others need to see the front panel "power" button
678 pressed. This is often configurable in the Bios.

679 The D8/0x100 and D9/0x200 bits are the most commonly set by a user. In
680 particular, if your system boots on power up, the D8 bit should be set.

681 Another useful bit is the D11 or 0x800 bit, which has the current state
682 printed out as it changes.

683 Someday there will be a state diagram in this document, however the code
684 may be updated or get bug fixes not reflected in the state diagram. It is
685 provided to illustrate the over concepts used by the microprocessor and the
686 various sensors to control the power supply and motherboard. Currently,
687 there are about 27 states in the state machine for the uP to control the
688 power supply system.

689

690

Composite Fault Bitmask

691 The next section shows the serial string that is sent from the power supply
692 to the server. One of the data elements in that string is the Composite Fault
693 Bitmask. The strings you can see have been covered above. Here are the
694 bit definitions for that mask:

695 0x0001 Over Temperature
696 0x0002 Under Temperature
697 0x0004 Battery Current Over Limit
698 0x0008 Server Current Over Limit
699 0x0010 Auxiliary Current Over Limit
700 0x0020 Server Chip Fault (the server chip had an over current,
701 over voltage, or short at some point)
702 0x0040 Server Chip Short
703 0x0080 Server Chip Over Current
704 0x0100 Server Chip Over Voltage
705 0x0200 Auxiliary Chip Fault
706 0x0400 Auxiliary Chip Short
707 0x0800 Auxiliary Chip Over Current
708 0x1000 Auxiliary Chip Over Voltage
709 0x2000 Faulty Temperature Sensor
710 0x4000 Emergency Low Battery Supply Shutdown
711 0x0800 Not assigned

712

713 The bits are set when there is an event. There is no count of how often the
714 fault happened, or of the duration of the fault.

715 Over and Under Temperature are set if the ambient temperature is outside
716 of the user configured limit at any time, including initial power up. Note that
717 this may not be an error, it just means that at some point in time the
718 supplies either had to wait to be powered up, or it was running and had to
719 power down. These bits being set just to advise technicians that the device
720 has been used in some extreme temperature conditions that would have

721 temporarily prevented the system from booting or would have taken the
722 system down after the configurable time delay.

723 The first 3 Over Current faults (0x4, 0x8, and 0x10) are set when the
724 current exceeds the user configurable current limit. The chip based over-
725 currents are set when the current drawn exceed the limit in the chip for
726 more than 3 mS. That limit is set by the software and is 6 amps for output
727 voltages < 8.1 volts, and 5 amps for output voltages >= 8.1 volts. The
728 power supply chip can provide substantially more current (15 amps) for up
729 to 3 mS in order to provide for a large increase in load (especially capacitor
730 inrush current) while maintaining voltage regulation.

731 The power supply outputs can be short circuited. The chip will periodically
732 (about every 78 mS) check to see if the short is still there. This reduces
733 power consumption and heating of the chip during a short circuit event.
734 When the short is cleared, normal operation continues (but devices using
735 the supply may be in an unknown state due to the power interruption).

736 Over-voltage occurs if the output is > 23.5 volts. Since the software limits
737 the range of output voltages (to 13V for the server, and 18 volts for the
738 auxiliary supply), this would be some spike or back feeding of the power
739 supply. The source of the overage must be tracked down.

740 If the battery drops to 6.3 volts or lower, both supplies are immediately shut
741 down. This is done while the power supply chips have good voltage and will
742 “behave correctly”. Note that your server will not have a change to be taken
743 down correctly. This action includes if you just “pull the plug” and
744 disconnect the battery.

745

746 **Server Serial Port Description**

747 The 10 pin ribbon connector is a serial port running at 38.4K Baud, “8-
748 none-1”. About every 4 seconds it supplies the server with information
749 about the state of the power supply, and if the server will be going down
750 soon. The C code for creating the string that gets sent to the motherboard
751 looks similar to this:

```
752 ///////////////////////////////////////////////////  
753 // Talk to the Unix system running on the motherboard  
754 ///////////////////////////////////////////////////  
755 void doTalkToMotherboard(void){  
756     printf("{\"Id\": \"MBSRVPWR\"");  
757     printf(", \"Bv\": %u", batteryVoltage);  
758     sprintf(s, ", \"Bi\": %u", batteryCurrent);  
759     printf(", \"Sv\": %u", serverVoltage);
```

```

760     printf(", \"Si\":%u", serverCurrent);
761     printf(", \"Av\":%u", aux12Voltage);
762     printf(", \"Ai\":%u", aux12Current);
763     printf(", \"So\":%u", supplyServerSupplyIsOn);
764     printf(", \"Ao\":%u", supplyAuxSupplyIsOn);
765     printf(", \"Ps\":%u", serverPowerSupplyState);
766     printf(", \"Bk\":%u", batteryOkVoltage);
767     printf(", \"Tc\":%u", currentAmbientTemperature);
768     printf(", \"Tm\":%u", minOperatingTemp);
769     printf(", \"Tx\":%u", maxOperatingTemp);
770     printf(", \"Th\":%u", maxTemperatureSeen);
771     printf(", \"Tl\":%u", minTemperatureSeen);
772     printf(", \"Bt\":%u", batterySupplyMaxCurrent);
773     printf(", \"Bp\":%u", batterySupplyPeakCurrent);
774     printf(", \"Sc\":%u", serverSupplyVoltage);
775     printf(", \"St\":%u", serverSupplyMaxCurrent);
776     printf(", \"Sp\":%u", serverSupplyPeakCurrent);
777     printf(", \"Ac\":%u", auxiliarySupplyVoltage);
778     printf(", \"At\":%u", auxiliarySupplyMaxCurrent);
779     printf(", \"Ap\":%u", auxiliarySupplyPeakCurrent);
780     printf(", \"Fb\":%u", compositeFaultBitmask);
781     printf(", \"Fs\":%u", lowBattShutdownCount);
782     stringPtr = addToEndOfString(stringPtr, ", \"Ds\":");
783     if(timeLeftUntilShutdown > 0xFFF0){
784         printf("-1");
785     } else {
786         printf("%u", timeLeftUntilShutdown);
787     }
788     }
789     Printf("}\n");
790 }

```

791 The format is a group of data elements, which each element being comma
792 delimited. The 1 or 2 character name of the data element is followed by a
793 colon, and then by the decimal value or a string value. The length of the
794 string can be up to 380 bytes, typically it's about 300 bytes long. A sample
795 output string looks like:

```

796
797 {"Id": "MBLSRVPWR", "Bv":13888, "Bi":228, "Sv":12017, "Si":246, "Av":1
798 2025, "Ai":2, "So":1, "Ao":1, "Ps":11, "Bk":12000, "Tc":77, "Tm":35, "Tx
799 ":130, "Th":77, "Tl":73, "Bt":14900, "Bp":960, "Sc":12000, "St":4900, "
800 Sp":256, "Ac":12000, "At":4700, "Ap":38, "Fb":16384, "Fs":1, "Ds":-1}

```

801 This is a JSON encoded data object.

802 The first data element looks like: "Id": "MBLSRVPWR". This is the Power
803 Supply ID, which is MBLSRVPWR for this circuit board. This lets server-
804 side software work with any future supplies that might have different data
805 elements that are sent to the server. This is also an example of when the
806 value of the data object is indeed a string and not a hex number.

807 Most of the data elements are self-explanatory from the names. The
808 “timeLeftUntilShutdown” is how long (in seconds) until the “Power Off”
809 button on the front panel is pressed, initiating a system shutdown. A value
810 of -1 means the supplies are not scheduled to go down. This lets the OS on
811 the mother board issue a warning to all users. The front panel switch will be
812 pressed (via J8) in order to start the system take-down process after the
813 number of seconds have elapsed.

814 *Detailed Description of JSON data elements:*

815 Color Coding of Values is:

816 **Blue** – user programable value

817 **Red** - Measurement of the value “right now”

818 **Green** – Log Value. A value logged by the system, typically a
819 Peak or minimum value

820 **Black** – Other values

821 All voltages are displayed and entered in milliVolts.

822 All currents are displayed and entered in milliAmps.

823 **Bv** – batteryVoltage - This is the battery voltage as seen on the power
824 supply board right now.

825 **Bi** - batteryCurrent - This is the amount of current being drawn from the
826 battery “right now”.

827 **Sv** - serverVoltage - This is voltage output for the server supply right now.
828 Units are Millivolts

829 **Si** - serverCurrent - This is the current the server supply is providing right
830 now. Units are milliAmps

831 **Av** - aux12Voltage - This is the voltage output of the Auxiliary supply right
832 now. Units are milliVolts

833 **Ai** - aux12Current - This is the maximum current coming out of the the
834 Auxiliary supply right now. Units are milliAmps

835 **So** - supplyServerSupplyIsOn - This is a Boolean for if the server supply is
836 turned on. While this may seem silly, since if the server is not up what is
837 reading this serial port, it allows for an external system to know the status
838 of the server power supply. Zero is off, any other number is on.

839 **Ao** - supplyAuxSupplyIsOn - This is a Boolean for if the Auxiliary supply is
840 turned on.

841 **Ps** - serverPowerSupplyState - This is the current state of the power supply
842 control state machine

843 **Bk** - batteryOkVoltage - This is the programmed voltage for the threshold used
844 to determine if the battery voltage is OK (> the threshold) or not. The range
845 is 6.5 to 14.5 volts. Keep in mind that the supply does a “hard and fast” turn
846 off of the power supplies at a battery input voltage of 6.3 volts. This value is
847 set to avoid draining a battery so far that the vehicle can not be
848 cranked/started.

849 **Tc** - - This is the ambient temperature right now

850 **Tm** - minOperatingTemp - This is the programable lowest temperature that the
851 supplies can be operating. The range is limited between 0 and 60 degrees
852 F.

853 **Tx** - maxOperatingTemp - This is the programable highest temperature that the
854 supplies can be operating. Together with the Tm, it defines the temperature
855 range over which the supplies can be operating. The range is limited
856 between 85 and 138 degrees F

857 **Th** - maxTemperatureSeen - This is the ‘h’ighest temperature seen by the system
858 at any point in time. This logs the maximum temperature seen.

859 **Tl** - minTemperatureSeen - This is the ‘l’owest temperature seen by the system.
860 Note that both the Th and Tc are the extreme temperatures seen when
861 there was ignition or whenever the supplies were up. This logs the
862 boundaries of the environment for the server.

863 **Bt** - batterySupplyMaxCurrent - This is the programmed threshold for battery
864 current above which a battery overcurrent exists. The range is 0 to 19
865 amps.

866 **Bp** - batterySupplyPeakCurrent - This is the peak/maximum battery current the
867 supply has ever drawn. A log of the maximum current seen.

868 **Sc** - serverSupplyVoltage - This is the programable voltage for the server
869 supply. This is the output voltage that the supply should be running at. The
870 range is 1.8 to 13 Volts, the units used are millivolts.

871 **St** - serverSupplyMaxCurrent - The server supply current threshold for
872 determining that an “overcurrent” has occurred. The range is 0 to 5 amps.

873 **Sp** - serverSupplyPeakCurrent - This is the peak current the server supply has
874 ever provided. Think “Peak current ever seen” log entry

875 **Ac** - auxiliarySupplyVoltage - This is the programable voltage for the auxiliary
876 supply. This is the output voltage that the supply should be running at. The
877 range is 1.8 to 18 Volts, the units used are millivolts.

878 **At** - auxiliarySupplyMaxCurrent - This is the programable threshold at which an
879 overcurrent exists. The range is 0 to 6 amps.

880 **Ap** - auxiliarySupplyPeakCurrent - This is the peak current the auxiliary supply
881 has ever provided.

882 **Fb** - compositeFaultBitmask - This is the fault bit mask, as defined above

883 **Fs** - lowBattShutdownCount - This is the number times the supply has ever had
884 to do an emergency shut-down and turn off the supplies due to the battery
885 voltage going below 6.3 volts. If the server seems to “keep crashing”, this
886 can be a clue that the input battery voltage keeps dipping too low, even if
887 it’s just for 10 mS.

888 **Ds** - timeLeftUntilShutdown - This is the number of seconds until the front
889 panel power button is pressed to start the server shut-down. A value of -1
890 means no shutdown is anticipated.

891

892

893

Summary and Future Work

894 The microprocessor used here is a Texas Instruments MPS430FR2155. It
895 has 32 kB of MRAM (like Flash) for the program and 4 KB of ram.
896 Currently, the program takes about 30 K, and ram use is about 2500 bytes.
897 Some of the program space must be reserved for big fixes.

898 As the supply is used, there may be additional parameters for the
899 Config/EEPROM settings that need to be created. There is no easy
900 upgrade path for the uP in the package used- it’s about maxed out for this
901 series of part.

902 As hinted at in this data sheet, the part is heavily targeted around the
903 SuperMicro SCE300 chassis with the A2SDI-xx-HLN4F series
904 motherboards in the -2C (two core), -4C (four core) and -8C (eight core)
905 processors. Do not use the 12 and 16 core parts unless you really know
906 what your software will be doing. Doing computationally intense operations

907 such as video transcoding can use all the processors on the chip and that
908 would require more current than this supply can provide.

909

910 Here is a picture of the entire system, mother board and supply:

911

912

A2SDI-8C-HLN4F in the SCE300 Chassis

913

914