




FROM ROBORIO MXP PORT




MXP PASSTHROUGH PORT




\* pins are only on TEENSY 3.6.  
(x) pins are LC numbering.

To use TEENSY-LC, jumper pins 44 to 29, and 45 to 30.



RN52.2 33  
RN52.1 33

 SURLEE <span>for surlee electrical engineers everywhere</span>	
Title: teensyRIO by Surlee	
Document: 190-7023	Rev: A
Date: 1/6/2017 10:13 PM	Sheet: 1/1